

Mailing Address: PO Box 1674 Warsaw, IN 46581-1674 Phone: 844-SEYMOUR FAX: 574-267-8508 www.seymourmidwest.com Shipping Address: 2666 S Country Club Rd Warsaw, IN 46580

# **CAM<sup>®</sup> Gauge Rake** Assembly Instructions

## Tools Needed for Assembly:

7/16" wrench (two)

# Parts Shipped with Unit:

- Head assembly
- Threaded handle adapter or aluminum handle (not pictured)
- Gusset brace (set of 2) one gusset is labeled
- Bolt bag for braces CAM<sup>®</sup> sets are ordered separately and may or may not be shipped with this unit

#### **Gusset Brace Instructions:**


- 1. Slide slotted handle or threaded handle adapter over the center hole on the aluminum frame.
- 2. Position labeled gusset on bottom of handle/adapter, and the other gusset on top of the handle/adapter as shown.
- 3. Insert the two longest bolts through the top gusset, the handle/adapter and the bottom gusset. Insert the two shorter bolts through the two remaining holes on the frame.
- 4. Tighten all nuts, being careful not to over-tighten. Over-tightening hardware may result in crushing the handle, thereby compromising its strength.

## CAM<sup>®</sup> Assembly:

- 1. Remove the wing nut and loc washer on each end of the head assembly.
- Place the CAM<sup>®</sup> on the head, as shown, followed by the loc washer. Secure with wing nut. Do the same on the opposite end of the head.
- 3. Make sure CAM<sup>®</sup> striking surface is in line with screed edge, as pictured.

#### FULL WARRANTY

All Seymour Midwest products carry a full warranty against manufacturer defects in quality and workmanship. Products which have been abused or worn out from normal use are excluded from this warranty. We reserve the right to replace or issue credit on an individual basis.







REPLACEMENT PARTS LIST See Reverse Side

# CAM<sup>®</sup> Gauge Rake Replacement Parts

CA10004	10" CAN <sup>®</sup> Course Dake Frame Only
SA10084	10" CAM <sup>®</sup> Gauge Rake Frame Only
SA10086	12" CAM <sup>®</sup> Gauge Rake Frame Only
SA10089	24" CAM <sup>®</sup> Gauge Rake Frame only
SA10151	36" CAM <sup>®</sup> Gauge Rake Frame only
SA10152	48" CAM <sup>®</sup> Gauge Rake Frame only
SA20172	Handle – 66" yellow powder-coated aluminum w/ black grip
SA20171	Handle – 82" yellow powder-coated aluminum w/ black grip
SP20025	Threaded Handle Adapter
SA30009	Gusset Braces (set of 2)
SA60023	Bolt Bag – 4 bolts, 4 loc nuts (for handle attachment)
RM60036	Wing Nut
RM60107	Loc Washer
SP50002	Grip – 6" black
57078	CAM <sup>®</sup> – Size A with six settings @ 1/32" (set of 2)
57079	CAM <sup>®</sup> – Size B with six settings @ 1/24" (set of 2)
57080	$CAM^{\text{e}}$ – small combo with 5 settings, 1/16" thru 5/16" (set of 2)
57081	CAM <sup>®</sup> – Size 1 with three settings @ 1/16" (set of 2)
57082	CAM <sup>®</sup> – Size 2 with three settings @ 1/8" (set of 2)
57083	CAM <sup>®</sup> – Size 3 with three settings @ 3/16" (set of 2)
57084	CAM <sup>®</sup> – Size 4 with three settings @ 1/4" (set of 2)
57085	CAM <sup>®</sup> – Size 5 with three settings @ 5/16" (set of 2)
57086	CAM <sup>®</sup> – Size 6 with three settings @ 3/8" (set of 2)
57088	CAM <sup>®</sup> – Size 8 with three settings @ 1/2" (set of 2)
57090	CAM <sup>®</sup> – Size 10 with three settings @ 5/8" (set of 2)
57096	CAM <sup>®</sup> – Size 16 with three settings @ 1" (set of 2)