

Step #	Installation Step	Installation Methods	Products & Mix Ratios	Theoretical Coverage Rates
	Surface Preparation			
1	(Minimum CSP 3)	Shot blast or diamond grind	N/A	N/A
	Other Surfaces:	White pad buff, solvent wipe		
	Apply 1st Coat of MiraGuard Enriching Sealer	b. Airless Spray and	MiraGard Enriching Sealer	1000 -1200 SF/Gal
2	Caution: Avoid application of sealer when surfaces are hot from the sun. Attempt to schedule work during cooler hours and in more shady areas.	Backroll or c. Hudson-type sprayer and Backroll d. Brush for detail work	NOTE: Wipe excess amounts up with soft, dry cotton cloth or absorbent paper towels. Do not leave any residual wet films, all materials must penetrate. Product is designed to	Note: Coverage depends on surface texture and profile. Consumption may
			penetrate and is not designed to leave a film on the surface.	be greater on more irregular surfaces.
	Apply 2nd Coat of MiraGard Enriching Sealer	a. Dip and Roll or b. Airless Spray and	MiraGard Enriching Sealer	1000 -1200 SF/Gal
3	Caution:	Backroll or	NOTE:	
	Avoid application of sealer when surfaces are hot from the sun. Attempt to schedule work during cooler hours and in more shady areas.	c. Hudson-type sprayer and Backroll d. Brush for detail work	Wipe excess amounts up with soft, dry cotton cloth or absorbent paper towels. Do not leave any residual wet films, all materials must penetrate. Product is designed to penetrate and is not designed to leave a film on the surface.	Note: Coverage depends on surface texture and profile. Consumption may be greater on more irregular surfaces.

Note:

Prior to starting the application of any Miracote Product or System be sure to read the Installation Guide(s), Product Data Sheets, MSDS and other pertinent documents published by Crossfield Product Corp. for information, including but not limited to, Precautions, Limitations, Disclaimers and Warranties.



Pay special attention to substrate moisture content, physical condition of the substrate, method(s) of surface preparation, surface restoration, detailing of cracks, joints, transitions and terminations, and any applicable specifications. Review carefully for unknown site conditions or defects.

The theoretical coverage rates stated in the Installation Guides are for estimating purposes only. Factors, such as, allowance for material waste, unusual or abnormal substrate conditions and other unforeseen job site conditions that may affect actual product yields are the responsibility of the installer.