



DURAL AQUA-DAM LV

LOW VISCOSITY, HYDROPHOBIC POLYURETHANE GROUT

DESCRIPTION

DURAL AQUA-DAM LV is a low viscosity, hydrophobic polyurethane compound that is injected into hairline cracks in concrete and other sound substrates to stop water from entering into occupied or unwanted places. The reaction time of the DURAL AQUA-DAM LV is controlled through the use of its accelerator, known as DURAL AQUACCELERATOR. DURAL AQUA-DAM LV forms a water tight seal within the substrate that remains even if the water subsides.

PRIMARY APPLICATIONS

- Sealing fine cracks and joints
- Sewers & manholes
- Can be used in porous soils as a stabilizer
- Below grade walls subject to high water tables
- Wastewater treatment facilities

FEATURES/BENEFITS

- Low viscosity for smaller cracks
- Fast reaction time with added accelerator
- Bonds to wet and dry substrates
- Needs very little water to react and cure
- Remains active when the water subsides
- Excellent elongation to handle moving cracks and joints

TECHNICAL INFORMATION

TYPICAL PROPERTIES - LIQUID	RESULTS	TEST METHOD
Viscosity @ 77°F (25°C)	100 cps	ASTM D1638
Specific Gravity	1.17	-
Physical State	Liquid	-
Color	Amber	-

TYPICAL PROPERTIES - CURED	RESULTS	TEST METHOD
Density	4 lb/ft ³ (64 kg/m ³)	ASTM D1622
Elongation	48%	ASTM D638
Tensile Strength	25 psi (0.17 MPa)	ASTM D638
Shear Strength	19 psi (0.13 MPa)	ASTM D273
Water Absorption	< 1% by volume	ASTM D2842

TYPICAL REACTION PROFILE			
AQUACCELERATOR PERCENTAGE	0%	1.25%	2.5%
Initial Foam	Not Recommended	45 sec	30 seconds
Reaction Time	Not Recommended	3 min	1 min 45 seconds

PACKAGING/YIELD

DURAL AQUA-DAM LV is packaged in 5 gal (19 L) pails and 55 gal (208 L) drums. DURAL AQUACCELERATOR is packaged in 1 pint (0.47 L) cans and 5 gal (19 L) pails. DURAL PUMP RINSE is packaged in 5 gal (19 L) pails only.

SHELF LIFE

1 year in original, unopened container

DIRECTIONS FOR USE

Surface & Crack Preparation: To ensure the project is completed properly, clean the exterior of the surface so that the full extent of the crack or joint can be seen. This will aid in proper hole drilling. Start by knowing the thickness of the concrete substrate that is to be repaired. This will be used in the spacing of packers. Starting at the lowest point of the crack; triangulate the position of the first hole to be drilled, so that it will intersect the crack at a 45° angle, half-way through the thickness of the concrete. Drill a 5/8" (16 mm) hole in this position and ensure that the bit used is long enough to pass through the crack. Drill the next hole in the same manner on the opposite side of the crack. The spacing between holes should be equal to the thickness of the concrete. Continue to drill holes in the same manner, moving up the crack until the entire length of the crack or joint has an equal chance of receiving the grout. Install 5/8" (16 mm) injection packers into the drilled holes and tighten. Inject water through the packers to make sure they don't leak around the sides. This water injection will also flush out any dust and debris that is in the crack due to the drilling process.

Mixing: Prior to injecting DURAL AQUA-DAM LV, properly stir the material and the accelerator. Do not use high speed mixing equipment, for that will "whip" air into the product. Pour the appropriate amount of DURAL AQUACCELERATOR into the DURAL AQUA-DAM LV and mix on slow speed for a minute or two, to ensure the accelerator is fully mixed in. The mixing ratios are as follows:

DURAL AQUA-DAM LV

DURAL AQUACCELERATOR

Package Size	Standard Amount	Minimum	Maximum
5 gal (19 L) Pail	16 oz. (0.47 L)	8 oz. (0.24 L)	32 oz. (0.94 L)
55 gal (208 L) Drum	1.25 gal (4.75 L)	80 oz. (2.4 L)	2.5 gal (9.5 L)

The standard mixing ratio should be used in most instances. Do not go below the minimum mixing amount, for the material will struggle to react, especially in colder weather. Do not add more than the maximum amount of accelerator for the material will face a great risk of shrinking, thus allowing water to pass through the crack or joint again.

Placement: Once the injection packers have been set and the drilled holes and crack have been flushed out with water, the injection of the material can begin. Start at the lowest point of a vertical crack and work upwards. Pump DURAL AQUA-DAM LV into the packer until foaming material comes out the face of the crack and starts to approach the next packer. On a horizontal crack, start at the end that was first installed and flushed with water. The more water left in the crack and injection site, the better. Move the injection head to the second packer and repeat until you have moved the entire length of the crack. A standard airless paint pump can be used for this application. Typical injection pressure into cracks is 200-3000 psi (1.4-20 MPa), depending on the width and depth of the crack. Once the DURAL AQUA-DAM LV has cured, the packers can be removed or cut off, flush with the surrounding surface. The grout that has cured outside of the face of the crack can be cut back with a margin trowel or similar scraping tool. The packer holes can then be filled in with Euclid Chemical's Speed Plug hydraulic cement and finished as desired.

CLEAN-UP

Use all appropriate protective equipment. Avoid contact with the active grout. Use DURAL PUMP RINSE to clean out the lines of the injection equipment. DURAL PUMP RINSE can then be left in the lines as a primer, prior to the next project. Be sure to expel all DURAL PUMP RINSE from the lines prior to the next grouting job, for it will drastically affect the curing capability of the grout.

PRECAUTIONS/LIMITATIONS

- Colder temperatures will affect the viscosity and setting times of the product.
- Avoid exceeding 90°F (32°C) when warming product.
- Water used to react DURAL AQUA-DAM LV must be in the pH range of 3-10.
- Store material in moisture free packaging. Atmospheric moisture may cause a foam "head" inside of pail. This can be peeled off and the material below can still be usable.
- In all cases, consult the Safety Data Sheet before use.

Rev. 06.19

WARRANTY: The Euclid Chemical Company ("Euclid") solely and expressly warrants that its products shall be free from defects in materials and workmanship for one (1) year from the date of purchase. Unless authorized in writing by an officer of Euclid, no other representations or statements made by Euclid or its representatives, in writing or orally, shall alter this warranty. EUCLID MAKES NO WARRANTIES, IMPLIED OR OTHERWISE, AS TO THE MERCHANTABILITY OR FITNESS FOR ORDINARY OR PARTICULAR PURPOSES OF ITS PRODUCTS AND EXCLUDES THE SAME. If any Euclid product fails to conform with this warranty, Euclid will replace the product at no cost to Buyer. Replacement of any product shall be the sole and exclusive remedy available and buyer shall have no claim for incidental or consequential damages. Any warranty claim must be made within one (1) year from the date of the claimed breach. Euclid does not authorize anyone on its behalf to make any written or oral statements which in any way alter Euclid's installation information or instructions in its product literature or on its packaging labels. Any installation of Euclid products which fails to conform with such installation information or instructions shall void this warranty. Product demonstrations, if any, are done for illustrative purposes only and do not constitute a warranty or warranty alteration of any kind. Buyer shall be solely responsible for determining the suitability of Euclid's products for the Buyer's intended purposes.