


# INSTALLING SILL CORNERS



Using Fortifiber's Moistop Corner Shield® and Moistop Rigid Corner Shield

The lower corner of the sill is a vulnerable spot for water intrusion. That is why the Fortifiber Building Systems Group® has developed Moistop Corner Shield and Moistop Rigid Corner Shield. Incorporating these pre-formed corners with any of the existing flashing methods will provide extra insurance against water intrusion.



Compliance with the building code and proper installation are critical in reducing potential water leakage points. This is the responsibility of the Contractor. Fortifiber recommends the use of a well integrated weather-resistive barrier with all of its flashing systems.




## 1 INSTALL SILL FLASHING



## 2 INSTALL CORNER SHIELDS



## 3 INSTALL SILL WRAP




Pages 2 and 3 of this guide show how to integrate the sill corner into the most common window flashing methods. For detailed versions of approved window flashing methods, visit:

[www.fortifiber.com](http://www.fortifiber.com)


Call 1-800-773-4777 for Technical Assistance

**Limitations:** For optimum adhesion, Moistop E-Z Seal and FortiFlash flashings should be applied at temperatures between 40° F (4.4° C) and 120° F (48.9° C); FortiFlash Commercial may be applied at temperatures between 40° F (4.4° C) and 120° F (48.9° C); FortiFlash Butyl may be applied at temperatures between 25° F (3.9° C) and 125° F (51.7° C). FortiFlash, FortiFlash Commercial and FortiFlash Butyl are the only Fortifiber flashing products that can be installed horizontally or at a slope of less than 60°. Product should be covered as soon as possible. Inspect product to insure it is free of any protrusions or damage which may compromise its moisture-resistive properties. FortiFlash is not compatible with EPDM or flexible (plasticized) Polyvinyl Chloride (PVC) based products. FortiFlash also is not compatible with some sealants. Consult with sealant manufacturer for compatibility information. Direct exposure of sealant to the adhesive side of FortiFlash can be detrimental if the amount of sealant exceeds what is specified above. Please follow these recommendations regarding location and amount of sealant to be used. Fortifiber strongly recommends against the practice of using a "knockdown bead of sealant," or "buttering the flange" with sealant, because this amount of sealant is excessive and unnecessary.


# HIGH PERFORMANCE WINDOW FLASHING




# METHOD "A1" WINDOW FLASHING



# METHOD "A" WINDOW FLASHING



# METHOD "B" WINDOW FLASHING



For detailed versions of all four of these installation methods, visit [www.fortifiber.com](http://www.fortifiber.com).  
Call 1-800-773-4777 for Technical Assistance



Protecting Your World from the Elements®

NATIONAL SALES OFFICE - Fernley, NV

# INSTALLING SILL CORNERS

## Air Barrier Supplemental Detail

Using Fortifiber's Moistop Corner Shield® and Moistop Rigid Corner Shield

This supplement is to be used to replace Detail 2 in the Corner Shield Installation Guide in an air barrier installation. Additional sealant is placed in the intersecting corner of the sill and jambs, as well as along the face of the window behind Moistop Corner Shield.

### 2 INSTALL CORNER SHIELDS

