

# **MetalTex Aggrelime**

### **Systems**

Aggre-flex EIFS
Aggre-flex Drainage EIFS
Cemplaster Fiberstucco
ICF Coatings
QRW1 Drainage EIFS
Rollershield Drainage CIFS®
Soffit System
Stucco Cement Board Coatings
Uninsulated Finishes

VOC: <50 g/L Manufacture Locations: 30058 • 77474 • 84651

Packaging: 5 gallon (19L) pail
Pail Weight: 65 lbs (29 kg)
Shelf Life: 2 years
Coverage (estimated)
Typical Application: 125 sf (14 sm)

MetalTex Aggrelime is integrally an infused metallic look texture and finish for small areas of trim or surfaces. ultra-fine surface textured is easily applied unique replicates and subtle variations textures and of metallic surface.

- Unique visual appeal.
- Light finish texture replicates a sandblasted surface.
- Cost effective alternative to metal panels.
- Less expensive than metal panels.
- DPR (Dirt Pickup Resistant) polymer technology for long life and cleaner buildings.
- For small areas of trim or walls. Not for large areas.







## **MetalTex Aggrelime**

Temp: 40°-110°F (5°-43°C)•Working Time: .25 hr•Set Time: 8-12 hrs•Dry Time: 48-72 hrs at room temperature, working and drying time will vary with temperature and humidity

## **Application Procedure**

Job Conditions - Air and substrate temperature for application of MetalTex Aggrelime must be 50°F (10°C) or higher and must remain 50°F (10°C) or higher for a minimum of 24 hours. Provide temporary protection to protect the wall system from damage until permanent flashings, caps and sealants are installed. Store materials within prescribed temperature limits and out of direct sunlight. High temperatures will reduce working times, Low temperatures and/or high humidity will extend working, set and dry times.

Preparation - The substrate must be approved by Master Wall Inc.®, clean, dry, structurally sound and free of efflorescence, oil, grease, form release agents and curing compounds or anything that would affect bond. Painted surfaces are not acceptable and must be removed. Concrete and surfaces should cure for a minimum of 28 days. Stucco should be cured until clean, dry and hard—typically 7-14 days. Surfaces where MetalTex Aggrelime is applied must be very small in surface area.

Interior Drywall- Prime surfaces with Sanded Primecoat primer prior to finishing. Bond test prior to application on previously painted surfaces.

Base Coats - Must be flat, dry hard, and free of efflorescence. Master Wall base coats must cure a minimum of 12 hours before application of Superior Finish. Substrates of brick, masonry or concrete should be leveled smooth using either Master Wall base coats or stucco.

Mixing - Thoroughly stir MetalTex Aggrelime using a heavy duty 1/2" (12.7 mm) drill at 400 - 500 rpm and a heavy duty mixing paddle. Small amounts of clean, potable water may be added to obtain a workable consistency. To avoid unintended color variations, add the same amount of water to each pail. Do not exceed 3 ounces (0.1L) of water per pail of finish.

Application — Apply MetalTex Aggrelime to match the approved sample texture or effect using the selected tools and techniques. Extra care is needed to ensure a very smooth base coat has been achieved as the finish will not cover wall irregularities. Using a stainless steel trowel, apply MetalTex Aggrelime to a uniform but tight thickness. Allow this first coat to dry to the touch and apply a thin second coat and allow it to take up. Floating or finishing options:

- Float the finish lightly with a plastic float. Produces a lightly mottled, fine finish.
- After the second coat finish has taken up slightly, trowel again in one direction with a stainless steel trowel. Produces a super smooth finish.

For consistency, use the same methods and application techniques across the entire wall surface.

The MetalTex Aggrelime finish is intended to replicate the appearance of natural limestone. The application technique will have larger flat areas with small pit marks and possibly burn marks and varied color/texture conditions. This variation is intentional and part of the properties of this finish. For best results two thin coats are recommended.

For Professional Results

Apply finish coats away from direct sunlight. Cold joints or color variations can occur if the finish dries too quickly.

Consider priming stucco surfaces with Primecoat to even out finish absorption.

Surfaces exposed to the weather must be sloped (6:12 minimum).

Do not apply to gypsum board or insulation board products.

31808

Do not apply to large areas.

GA

Clean Up—Tools and equipment can be cleaned with soapy water while the MetalTex Aggrelime is still wet.

### Approved Substrates

Master Wall Base Coats
Stucco
Prepared & Base Coated
Surfaces of:
Brick
Concrete
Masonry
Interior Drywall made
ready for paint
Others approved in writing

**PO Box 397** 

Information contained in this product data sheet conforms to the standard detail recommendations and specifications for the installation of Master Wall Inc. Products and is presented in good faith. Master Wall Inc. assumes no liability, expressed or implied as to the architecture, engineering, or workmanship of any project. This information may be concurrent with, or superseded by other applicable documents, such as specifications and details. Contact Master Wall Inc. for the most current product information.

**Fortson** 



800-755-0825 • Tech: 800-760-2861